

Frame built

1. We tap holes with the taps into alu-extrusions to merge it with 3d printed mcs l-connectors (60×60) and endkappe,,. 2. We connect two horizontal extrusions with other two and screw mcs winkel-stabil (40×20) together. 3. We add angle connectors (mcs_winkel_stabil_40x20) to support the new struts 4. We connect third horizontal bar to the just build rectangle 120mm from the rear horizontal extrusion using angle connectors (mcs_winkel_stabil_40x20) 5. We add end covers (mcs_endkappe_40x20) to the sides of the foremost and hindmost extrusions